

BRAMAH FITTING INSTRUCTIONS

For ROLA FM Metal Fanlight Window Lock

Tools required

Electric Drill with 6.5mm twist drill
Centre Punch
Pliers

1 Remove the bolt by pulling retaining pin out with pliers.

2 Position lock body approximately 5mm from retaining bracket. Drill two 6.5mm \varnothing holes in stay arm on 20mm centres or use one existing hole enlarged to 6.5mm \varnothing .

If required, fit the 6mm packing piece, 3mm packing is available (R 3/06).

3 Secure to stay arm with top hat nuts and screws ensuring that the larger holes on the body, face into the room. Replace bolt, with key operating side facing into room, and secure by pushing in retaining pin.

4 To operate push the bolt fully to the right or left and using a standard ROLA key (R 6/01), lock the bolt in position.

Contact Details

Enquires, catalogues, requests for quotes and all matters historical, not on this CD, can be directed to sales at any one of our three business units at **Bramah, 31 Oldbury Place, London W1U 5PT** or by the following contact numbers:

Lock Manufacturing - Bramah and Rola Lock sales

Alpha Dial Telephone: +44 (0) 8700 BRAMAH (272624)
Facsimile: 44 (0)20 7935 2779
Email: lock.sales@bramah.co.uk

