

BRAMAH FITTING INSTRUCTIONS

For ROLA Hinge Bolt

Tools required

Brace with 20mm (25/32") and 9.5mm (3/8") wood bits
Bradawl
Chisel - 25mm (1")
Mallet
Pencil
Sharp knife
Rule
Screwdriver - medium

1 Drill a 9.5mm diameter hole, 40mm deep, centrally in the edge of the door, approximately 50mm below the top hinge.

2 Drive home the ribbed portion of the into 9.5mm hole.

3 Carefully close the door so that the bolt marks the door frame. Using this mark as a guide, drill a 20mm diameter hole, 20mm deep to received the bolt.

4 Check that the bolt engages easily as the door shuts.

5 Position the plate centrally over the 20mm hole and screw into position. Mark round the plate with a sharp knife, remove the plate and chisel out a 2mm recess. Counter-bore the screw holes to accept the pressings on the under side of the plate, check that the bolt still enters easily and then screw the plate flush in the recess.

6 Repeat instructions to fit the second hinge bolt approximately 50mm above the bottom door hinge.

Contact Details

Enquires, catalogues, requests for quotes and all matters historical, not on this CD, can be directed to sales at **Bramah, 31 Oldbury Place, London W1U 5PT** or by the following contact numbers:

Lock Manufacturing - Bramah and Rola Lock sales

Alpha Dial Telephone: +44 (0) 8700 BRAMAH (272624)
Facsimile: 44 (0)20 7935 2779
Email: lock.sales@bramah.co.uk



Application

